



# Soundproof Micro Data Center

**O&M** Manual



We engineer for a sustainable tomorrow.

### USystems Legal Disclaimer

The information presented in this manual is not warranted by USystems Ltd to be authoritative, error free, or complete. This publication is not meant to be a substitute for a detailed operational and site specific development plan. Therefore, USystems Ltd assumes no liability for damages, violations of codes, improper installation, system failures, or any other problems that could arise based on the use of this Publication. The information contained in this Publication is provided as is and has been prepared solely for the purpose of evaluating data center design and construction. This Publication has been compiled in good faith by USystems. However, no representation is made or warranty given, either express or implied, as to the completeness or accuracy of the information this Publication contains.

IN NO EVENT SHALL USYSTEMS LTD, OR ANY PARENT, AFFILIATE OR SUBSIDIARY COMPANY OF USYSTEMS LTD OR THEIR RESPECTIVE OFFICERS, DIRECTORS, OR EMPLOYEES BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL, OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS, CONTRACT, REVENUE, DATA, INFORMATION, OR BUSINESS INTERRUPTION) RESULTING FROM, ARISING OUT, OR IN CONNECTION WITH THE USE OF, OR INABILITY TO USE THIS PUBLICATION OR THE CONTENT, EVEN IF USYSTEMS HAS BEEN EXPRESSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. USYSTEMS RESERVES THE RIGHT TO MAKE CHANGES OR UPDATES WITH RESPECT TO OR IN THE CONTENT OF THE PUBLICATION OR THE FORMAT THEREOF AT ANY TIME WITHOUT NOTICE.

Copyright, intellectual, and all other proprietary rights in the content (including but not limited to software, audio, video, text, and photographs) rests with USystems Ltd or its licensors. All rights in the content not expressly granted herein are reserved. No rights of any kind are licensed or assigned or shall otherwise pass to persons accessing this information.

This Publication shall not be for resale in whole or in part.

### Contents

Packaging	 4
Important Safety Information	
Safety Symbols	 5
Safety Indicators	 5
Safety Instructions	 6
Model identification	 7
EDGE-3 Installation	
Moving the EDGE-3	 8
Electrical Installation	 9 - 10
Configuration	 11 - 13
Mounting angle adjustment	 14 - 15
Door removal - Front	 16
Door removal - Rear	 16
Fan panel removal	 17
Cable entry system	 18
Gland plates	 19
Extension kit assembly	 20
Plinth kit assembly	 21
EDGE-3 DAX kit assembly	 22
EDGE Management System	
Operation	23
Product Description	 24
Quick starter guide	 25
WebUI	
Overview	 26
Dashboard	 27
Fan Speed	 28
Environmental	 29
Security	 30
Alerts	 31-32
Reporting	 33 - 36
Settings	
Network	 37
Device Manager	 38 - 40
User Accounts	 38
Sensor Names	 39
SNMP	 39-40

### Packaging

### Inspection

Inspect the packaging and contents for shipping damage. Make sure that all parts are accounted for. Report any damage immediately to the shipping agent. Report missing contents, damage, or other problems immediately to USystems or your reseller.

Please Recycle The shipping materials are recyclable. Save them for later use, or dispose of them appropriately.



### Important Safety Information

Read the instructions carefully to become familiar with the equipment before trying to install, operate, service or maintain it. The following messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.

### Safety Symbols

The following symbols and markings related to safety are used on the EDGE system, the EMS and throughout this document. Their definitions are as follows:



This symbol indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety symbol indicates a warning/caution to a potential hazard or that and an appropriate safety instruction should be followed



This symbol indicates that the item is heavy or risk of injury and may require two persons or appropriate lifting equipment to carry or manoeuvre. Appropriate lifting and carrying instructions should be followed.



AC

This Marking (when used), indicates that product is configured for 100 to 130V operation

This Marking indicates that product is configured for 200 to 240V operation

### Safety Indicators

The following are used throughout the documentation to indicate the appropriate hazard or instruction related to safety.

# **A** DANGER

**DANGER** indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

# **WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

# **A**CAUTION

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

# CAUTION

**CAUTION**, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage.

# NOTICE

**NOTICE** addresses practices not related to physical injury including certain environmental hazards, potential damage or loss of data

### Introduction

### Safety Instructions

- The EDGE system is to be powered from a dedicated power source (Refer to Model Identification & Rating plate for voltage input).
- The EDGE system is not to be powered via an extension cord.
- The EDGE System Fans are factory installed and configured for either 100-130V or 200-240V (Refer to EDGE Rating plate and EMS marking for the voltage set to).
- The EMS appliance outlets are for the EDGE fan power only. DO NOT plug any other appliance into the EMS power Outlets.
- When performing maintenance, the EDGE System should be Isolated or the appropriate instructions followed.
- When Installing equipment within the EDGE ensure additional safety Instructions are specified.
- Power and distribution cables should be installed and routed so that they are unlikely to be damaged in normal operation.
- Cable ingress to the equipment should only be made via the dedicated cable entry points.

### Introduction

### EDGE-3 Model Identification

The EDGE model configuration shall be identified by the rating plate adhered on the external of the cabinet by the User display.

The model number nomenclature is defined as follows:

# $E_{a}[b]-[c][d]-[e]$

### Where:

[a]	=	3 =	Soundproofed	variant, 24 to 42L	J
L · J		-			

- [b] = Single alpha-numeric character for colour finish (Non safety critical)
- [c] = Height in U (model dependant), 24U to 60U
- [d] = Depth (dm) 06 to 14
- [e] = Voltage Input & Fan module: **15** = 100-130V or **24** = 200-240V

USystems	www.usystems.com +44 (0) 1234 761720 Systems House, 235 Ampthill Road
Madalı	Bedford MK42 9QG UK
woder:	E3G-2412-24
Hardware version:	P3-EDGE-xx
Software version:	V1.0
Serial number:	0000000
Input voltage:	200-240V, 50/60Hz, 5A
No of Fans / voltage:	2 x 200-230, 50/60Hz, 170W
DoM (mm/yy)	08/20
	S Conforms to UL Std UL 61010-1 Cert. CSA C22.2 #61010-1

Example of Identification/Rating label

The example above shows an EDGE-3 Soundproof cabinet, 24U in height, 120cm depth, configured for 240V input, with two fan modules (1 per door) rated 200-230V, 170W

# **A**CAUTION

### HAZARD

This cabinet can be tipped. Use extreme caution when unpacking or moving.

At least 2 people are required to unpack and move the cabinet.

Putting the cabinet in place of situ before installation of the equipment.

When moving the equipment after installation, isolate, disconnect and stow the power cable to prevent damage.

# **Unpacking instructions**



- The cabinet will be bubble and shrink wrapped as well as having protective cardboard corners.
- When unpacking the cabinet do not run a blade all the way through the packaging as it may scratch the cabinet paint. •
- Remove the cardboard corners by cutting the tape.
- Pull off the shrink wrap.
- Un-ravel the bubble wrap.

The cabinet will be unlocked and the keys located inside on the front mounting angles.

### **Moving the EDGE-3**

### Moving instructions

- When moving the cabinet with equipment inside, place the heavy equipment at the lower part of the 19 inch area.
- Maximum load on castors is 500kg. •
- Make sure the levelling feet are up and push the cabinet only from the front or rear when moving the cabinet on its castors. Never push the cabinet from the sides to avoid potential tipping.
- When installed ensure the adjustable feet are down and the cabinet is secured.

### **Electrical Installation.**

# **WARNING**

The EDGE-3 equipment is configure for either 100-130V fans or 200-240V dependant on the fans fitted, this will be indicated to the rear of the EMS rating label. Reference image below.

The EDGE System requires a dedicated Power Source.

An approved power cord type to a maximum of 3m in length should be used to power the EDGE System to ensure continued compliance.

Cables to be routed to avoid damage to the cables and prevent trip or other hazards.

The EDGE system is to be electrically installed in accordance with local and regional electrical codes.

Input Voltage range	100-130V / 200-240V, 50/60Hz, 5A max (Voltage input model dependant)**
Fan Module Voltage	Refer to EMS Rear panel & model Identification rating for configuration

Electrical supply to the EDGE System requires to be 100-130V or 200-240V 50/60 Hz from a 10A dedicated branch circuit protected supply.

Electrical connection to the EDGE system is made via the EMS located within the cabinet to an IEC 60320-1 C-14 fused appliance inlet.

\*\*The Voltage range input is dependent on the Fan module configuration. (Refer to model identification/rating label & the voltage "INPUT" marking located on the rear panel of the EMS.



Rear panel of EMS showing Voltage configured for 200-240V

The EMS provides supplementary protection via the fused inlet by 2 x High Rupture Capacity fuses rated T5AH250V.

The EDGE System for continued compliance must be provided with an appropriate Pre-approved power cord fitted with a regional plug to a maximum of 3 metres in length.

The power cord specification is defined below:

Type SJT or SVT / HO5VV-F <HAR., 3 x 18 AWG (1.0mm), 2C +PE rated 300V, VW-1 terminated with an IEC 60320-1 C13 appliance coupler and a regional plug.

The EDGE may be connected for permanent installation via a dedicated power source in accordance with local and regional electrical codes via an appropriately rated Isolator of which should be accessible and no more than 2 metres away from the EDGE Cabinet once installed

The EDGE power cable is to be installed via the cable entries fitted to the EDGE cabinet. Any Power cables to be provided to the EDGE cabinet both internally and externally, are to be routed to avoid damage and risk of further hazards.







Turn off the power to the EMS and Fans by selecting the switch shown left to the off position (currently showing as 'on' in the picture).

Turn off input power at source and remove the IEC Input connector to the EMS.

#### **INTERNAL EQUIPMENT**

Any electrical equipment to be installed within the EDGE System is to be suitably electrically protected, again consideration to power cable installation and routing both internally and externally is a must.

If electrical distribution blocks are to be used they should not be overloaded, and the ampacity should not exceed the rated capacity of the distribution block.

Consideration for isolating equipment to be installed within the EDGE Cabinet should also be made.

If rack sliders are used high up in the cabinet ensure that there is sufficient weight at the bottom of the cabinet to support heavy equipment to avoid the cabinet tipping. We recommend heavy equipment mount as low as possible.

### **Configuration**

Before installing the enclosure, plan the location and space needed to install equipment, and plan ergonomics of keyboards and video monitors. Improper airflow could damage installed components.

The following should be considered when finding a location for your enclosure

- Ambient temperature in the room should be as low as possible to allow efficient cooling.
- Do not install next to a radiator or heat source
- If installing with a DAX (Direct Airflow eXhaust) allow no more than 2m from a wall or window pan from the rear of the enclosure.
- Do not place the enclosure in direct sunlight or in a small non-air conditioned space.
- Place the enclosure close to ventilation or cool air ingress points in the room.



Airflow

### **Configuration - Cooling and best installation practice**

The EDGE-3 can achieve up to 12kW of heat removal. But in order to achieve these figures it is paramount that 'best installation practice' is adopted. Understanding the airflow characteristics of the EDGE-3 design is key.

### **Airflow characteristics**

The key difference between most 19" soundproof cabinets is the poor segregation between cold air entering into the cabinet and the IT equipment space – failure to deal with this results in hot spots and general heat recirculation issues.

The EDGE-3 deals with the problem by creating three separate zones – the first zone is the 'patent pending' double pass wardrobe front doors, ambient air passes through the full height of the doors and into the second zone.

This feature is of key importance as this allows a uniform flow of ambient cool air to be available at any 'U' position within the cabinet – so no equipment needs be starved of cool air. It is worth noting that this vertical space should be kept clear and that all cabling should be kept managed against the infill panels provided, using jumper rings or cable trunking . The result of best practice sealing - no hot air recirculation



**W** = Keep these areas clear of obstruction to air airflow

The second zone is the IT equipment space and sealing between the first and second zone is critical; the EDGE-3 cabinet comes as standard with foam infills which covers the periphery of the 19" area see Figs 2

#### and 4.

Cabling can pass through this area from front to rear but maintaining the seal's integrity is very important. In addition to the peripheral area the 19" aperture also needs to be treated in the same way – completely sealed. Unfortunately not all equipment comes in the standard 19" format, for this reason there are a number of solutions designed to assist in this process - see Fig 2 and 5.



The patent pending air inlet wardrobe doors enable the required volume of air to uniformly flow over the full height of the 'U' (usable) space on both sides of the cabinet, thus ensuring that all the enclosed IT equipment receive the necessary amount of air.



NB The active rear door on the 12U model exhausts hot air to the base of the door and not the top as in other height models

### Configuration - Cooling and best installation practice continued

It has long since been established that allowing heat recirculation in 19" cabinets results in IT equipment overheating which shortens its working life and more often leads to software and systems failures. Unfortunately this issue is compounded when using soundproof materials, owing to their heat insulation properties.

So to maintain optimum performance and a safe, controlled working environment for the IT equipment - one that overcomes hot spots and heat recirculation issues - it has to be dealt with by correct airflow management. Achieving this comes down to a combination of clever enclosure design and the application of best installation practice.

Keeping the vertical and horizontal cabling organised and managed is essential in order to allow ambient air to pass through onto the active equipment.

The foam running around the sides of the infills must be maintained to ensure its ongoing effectiveness.



EDGE-3 sound proof cable entry system enable cabling in and out of the cabinet without compromising both sound or thermal performance. There are six available ports in total, three at the top and three at the bottom of the cabinet so further cable entry systems



EDGE-3 blanking panels require no fixings and play an important role in both airflow and sound proof management. A major benefit is the prevention of hot air re-circulation which eliminates the risk of hot spots



EDGE-3 sound proof tower infill foam helps to retain maximum thermal performance and sound attenuation when fitting non 19" equipment such as a tower PC - available in 2 size kits to prevent hot spots and the potential over heating of active equipment



### Mounting angle adjustments

The mounting angles are factory fitted by default to 700mm. Both front and rear mounting angles are adjustable but it is advised to move the rear mounting angles to accommodate longer IT equipment.

### Adjusting the mounting angles

This task can only be performed when there is no IT equipment inside of the cabinet.

A Philips screwdriver and a 10mm spanner is needed to perform this task.

1. Take off both side panels to gain access to the depth support rails by opening both front and rear doors, turn the cam locks on the side panel to undo them from each depth support.



2.Use a Philips screwdriver and 10mm spanner (not provided) to remove the infill panels from the 3 depth support members.



3. Remove the mounting angle from the top and bottom mounting angle supports by using the Philips screwdriver and 10mm spanner.



4. Move the mounting angle and infills into the desired place. Screw the mounting angle back into the top and bottom mounting angle support and infills back into the 3 depth supports.



### Door removal - Front passive (non-fan)



When removing LCD door, make sure that the micro usb cable attached to the door has been disconnected.





Open both doors to 135° (does not need to be exact) to allow the most grip when holding onto the door and lift off both hinges.

### Door removal – Rear Active (Fan side)

Please follow local safety protocols Advisory 2 people to remove this door



Turn active door to a 135° position and unplug the IEC power connector and 6 way Molex as shown and lift the door of its hinges.



### Fan Panel removal

To removal/replace a fan panel turn off power to the fans.



)

1. Disconnect the IEC and fan connector cable from the fan panel





2. Using a Philips screwdriver unscrew the 9 screws surrounding the fan panel as shown

3. The fan panel will now slide out, reverse the removal procedure to install the fan module



### Cable entry system

The cable entry system can be used at any of the cable entry points by removing the gland plate and adding the cable entry system in its place.

Remove the gland plate by unscrewing the 2 m6 bolts and lifting the panel away from the enclosure. Keep somewhere safe if needing to put back.



Keep the cable entry foam together and feed it through the gland hole and firmly press down on the sides for a good seal.



Remove the yellow tape cover from the cable entry system foam.



Put cabling through and evenly distribute it along the cable entry system to allow for the best sealing.



### **Gland plates**

The EDGE-3 has 6 gland plates which are removable. It is advised not to remove the gland plates during operation as this will cause issues with air recirculation and potential hot spots.



To remove the gland plate unscrew using a Philips head screw driver while holding onto the nut to avoid dropping if removing from the top frame. Gland plates are put in tightly to create a seal so it can be stiff removing and place back in. To ensure optimum running efficiency it is important that seal integrity is maintained by utilising either cable entry system (page

18) or other forms of cable grommets.

### Extension Assembly kit

The EDGE-3 rear extension kit allows larger equipment to be put inside, giving an additional 200mm depth. It is fully retrofittable and will not adversely affect the performance of the cabinet.



- 1. Remove the rear active doors, following instructions on page 16.
- 2. Remove original hinges on frame using allen key via relief in corners post (rear of hinge).
- 3. Fix 4x retainer brackets onto lid and base using m6 fixings.
- 4. Fit extension unit using M6 fixings supplied into 4x retainer brackets (lid and base).
- 5. Attach the active doors and use the extensions cables provided to accommodate the extended length.

### **Plinth Assembly Instructions**

- 1. Remove the M10 allen key bolt and the M6 pozi nut and bolt from each corner of the base (note head of the M6 Bolt is located inside the cabinet).
- 2. Place the corresponding plinth corners (left hand and right hand) on each corner with the M6 bolt and nut and the M10 nut as per removal (make sure the levelling foot is attached to the plinth corner before fitting it onto the UCoustic base).
- 3. Once each plinth corner is fitted proceed to fit the external plinth panels using the M6 x 25 bolt onto a tapped hole on the plinth corner.
- 4. Unwind the levelling feet till the castors are floating.



### EDGE-3 DAX kit

The EDGE-3 DAX 'Direction Airflow eXhaust' kit is available to control the hot airflow exhaust from the active rear doors. Please see data sheet for more information. Not available on 12U EDGE-3.

### Stage 1



Stage 2



Locate ventilation interface to rear of cabinet lid lining up entry holes in both parts, ensuring that the gasket seals against lid edges.



Refit gland plate re-using M6 fixings. Alternatively use the cable entry system, which will also assist clamping down of the retrofit ventilation interface.



# EDGE Management System 'EMS'

Product User Guide

### Product Description EDGE Management System (EMS)

The EDGE (EMS) is the hub of the EDGE System. It provides the means of connection to the dedicating incoming power source and Fan power distribution and control

The EMS is a networkable, environmental, monitoring and security product.

This following is a list of ancillary devices currently available to install

- Temperature sensors up to 4
- EC Fans up to 2
- Contact sensors up to 6
- Aisle containment door open/close
- UTelligent Locking
- LCD Alarm Screen



### Quick starter guide

- 1. The EDGE Management System is delivered from USystems with default settings, please refer the EDGE Management System User Guide for these settings. These settings should be adequate for most installations, however adjustments can be made to suit the requirement.
- 2. The EDGE Management System (EMS) requires either 100-130V or 200-240V 50/60Hz dedicated input power source. (Refer to rating plate & model identification for details).
- 3. Once power has been applied to the EDGE Management System, the system shall initialise. The Active door fans shall run at full speed until the EMS has completed its boot up and started the control sequence.
- 4. The LCD screen will require boot up time and is communicating with the EDGE Management System via wi-fi, a delay of up to 5 minutes on boot up before communication has been established.
- 5. In order to use the WebUI (Web User Interface), an Ethernet cable from the EDGE Management System to your network is needed. Plug the Ethernet cable into the EDGE Management System RJ45 port and then to a live network port onto your own network. The network port on the EDGE Management System will light up to show it is live.
- 6. The default IP address to log on to the EDGE Management System is 192.168.0.10, please contact your network administrator if unable to load the log in screen.
- 7. The default login is 'admin' and the password is 'Admin12\$'
- 8. Accept the EULA to proceed onto the WebUI
- 9. The following pages detail modifying default settings on the EDGE Management System User Guide Page 19 -21

### WebUI 'Web User Interface' Overview

The EDGE Management System is an environmental, monitoring, security and networkable product, delivered with a default IP Address of 192.168.0.10 and a Net mask of 255.255.252.0

The WebUI can be accessed using the default IP address in the address bar of any browser from any type of device there is a default Administrative account which to login to requires the following credentials:

Default username: 'Admin'

Default password: 'Admin12\$' (case sensitive)

If unable to connect please contact the Network administrator to allow the use of this IP address or connect directly to the EDGE Management System via ethernet and adjust your IPv4 properties to match.

Once the EULA has been accepted it will redirect to the dashboard page once logging in successfully. By not accepting our EULA access will be denied the EDGE Management System software.

Curelligent         Username         Password         Remember Me         Forget Your Password?         Login         USystems Linited & 2020  v2:0		
Username Password Remember Me Forgot Your Password? USystems Liniked © 2020   v2.0		UTelligent
Password  Remember Me Forgot Your Password?  Login USystems Limited © 2020   v2.0	Username	ne
Forget Your Password?	Password	rd 📃 Remember Me
Login USystems Limited © 2020   v2.0		Forgot Your Password?
USystems Limited © 2020   v2.0		Login
		USystems Limited © 2020   v2.0

### WebUI - Dashboard

UMS	= UTell	igent	👗 Admin
🚯 Dashboard			
O Fan speed	Cabinet Status		
Environment	Cabinet Name	UMS359e39	
Alerts	Fan 1 - Status	ок	
Reporting	Fan 2 - Status	ОК	
€ Sattinge	Fan 1 - Speed	452 RPM	
• Settings	Fan 2 - Speed	461 RPM	
1 User manual	Temperature Sensor 1	21 (°C)	
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			- 8
			_
	USystems Limited © 2020   v2.0		

The dashboard is made up of different tables depending on your cabinet configuration.

### <u>Header</u>

Select the Username icon to Restart, Upgrade, Remote support and Log out.

Restart - Selecting this with restart the EMS

Upgrade - This option is available to upgrade the EMS To use this an update file from USystems will be required

SupportMe! - This is to enable the VPN connection with USystems so that a remote support connection can be established. Once the EMS is restarted the VPN connection will be disabled, select the SupportMe! Button again to re-enable, Log out - Selecting this will log the user out of the EMS and will return to the log in screen.

### <u>Menu</u>

Left side of the dashboard is the menu with a list of different options these areas can be locked out for certain users - please see page 20 for user accounts.

### **Cabinet Status Table**

Cabinet name: By default it is named as EMS followed by 6 digits from the MAC address - please see page 19 settings to change this. It is also the hostname for the device.

Fan Status: Displays the fan status and its value being either 'OK' or 'FAIL' - please see page 10 for fan alarm information

Fan Speed: Displays the RPM (Revolution per minute) of each fan

Temperature Sensor: The current temperature will be displayed along with the sensor location, it can be displayed in °C or °F Each sensor can be provided with a customer name, this can be done under **Settings - Sensor names**.

Digital sensors: Contact sensors will display if the cabinet is open or closed.

### WebUI - Fan Speed

The Fan speed page wil	I allow you to set an	alarm if there is a Fan Fail.
------------------------	-----------------------	-------------------------------

UMS	≡	UTelligent	🛎 Adr
🍘 Dashboard			
O Fan speed	Fan Fail Alarm:	◎ On ⑧ Off	Device Information
Environment	Fan Speed Curve	Standard •	
🜲 Alerts		Save Settings	Fan Fait Alarm to activate the email alarm reature select to "On" Fan Speed Curve option allows the option of setting the ramp rate that will
Reporting			work best with the current equipment setup. Standard This is set by default which is for low demand and provides the best
🗲 Settings			sound attenuation Aggressive If select will provide a higher curve which is best for high demand
i User manual			Custom This is set by adding the percentage value of speed increase between each degree starting from 24*C/75*F - PLEASE USE WITH CARE
			Select Save Settings button to save and activate
		USystems Limited © 2020   v2.0	
	-		

To enable an alarm, select Fan Speed from the left hand column. Select the 'on' button and enter at least one email address of those that need to receive a notification. See page 19 to set up SMTP settings (emails).

Fan Speed Curve should not be changed by anyone who does not understand 'Ramp rates' which should be set dependant upon the equipment being used inside of the cabinet.

<u>Ramp rate</u>: Is the rate at which the fans speed up per degree Celsius from the <u>Base speed</u>. They will keep speeding up at this rate until they are running at 100% (10V) i.e. they are not capped. They will hit 100% at a temperature dependant on the ramp rate set. This does not require a restart it will change when selecting save the settings.

There will be 2 different **set** ramp rates which are listed in the table below and a custom option to change the ramp rate by increasing/decreasing the percentage of fan speed per degree.



### WebUI - Environment

The environment page allows setting of alarms on over temperature. The Alarm will be set off if the temperature reaches the set threshold in degrees °C/°F—which can be changed either using the arrows provided or by manually entering it by selecting the text field in between the arrows.

UMS	=	${\mathcal U}$ Telligent		Å Admir
🚳 Dashboard				
O Fan speed	Temperature Alarm:	⊖ On ⊛ Off	Environment Information	_
Environment	Set Alarm Temperature ("C)	<b>-</b> 36 <b>+</b>		
Alerts		Save Settings	Temperature Alarm: Io activate the email alarm feature select to 'On' Set Alarm Temperature: Enter the value of when you want to be notified	
Reporting			Select Save Settings button to save and activate	
✗ Settings				
i User manual				
		USystems Limited © 2020   v2.0		

Click on Environment in the left hand column, select the 'on' button. Set the alarm temperature threshold to be notified of when temperature reaches the selected number. To receive email alarms See page 19 to set up SMTP settings (emails).

Click Save settings to set all changes

### WebUI - Security

The Security tab is only activated if either a camera front and/or rear, or contact sensors have been added to the device manager.

EMS	⊧ <i>'U</i> Systems	USystemsMasterAccess
EMS Dashboard Fan speed Environment Alerts Reporting Security Settings i User manual		UsystemaklasterAccess
	Activate Capture type Capture Quality Settings	+

### **Camera Settings**

Brightness, Contrast, saturation and Hue can be adjusted per camera, this is accessed from the toggle below the camera feed.

To adjust the image without having to open the doors the camera/s can be activated using the "Activate" buttons.

Capture type will change weather a video or image is captured.

Settings can be saved or reset using the buttons.

### Photographic Security Records

To view the photos/videos taken select the picture, the default view will show 12 images per page.

When selected these are the options available to use.

### WebUI - Alerts 1

The EMS has an alert option which will alert on the date you select. When the Alert is triggered the LCD Display on your enclosure with change to Amber.

UMS	=	<b>U</b> Telli	gent	💄 Admin
🚳 Dashboard			_	
O Fan speed	Servic	Alert Settings	Filter Alert Settings	
C Environment	Service Alert:	◯ On ● Off	Service Alert Information	
Alerts	Service Alert Date:	01/01/2020		
Reporting		Save Alert	Service Alert when the date of activation has been reached a will appear on the dashboard and show as Active and the LEC	new table row O on the cabinet
🗲 Settings			door will change to <b>Amber</b> Service Alert On/Off turns the service alert on	
i User manual			Service Alert Date allows you to choose the date for this aler	t to be activated
			Activate Alert activates this alert Dismiss will deactivate the alert and remove alert notification	ns
				_
		USystems Limited © 2020   v2.0		

### Service Alert

USystems are able to provide your enclosure with a service when ever you need. For more information on what is offered in a service please contact USystems.

To activate this option simple select the 'On' button and click on the date to choice or type it in yourself, then select save.

### WebUI - Alerts 2

The EMS has an alert option which will alert on the date you select. When the Alert is triggered the LCD Display on your enclosure with change to Amber.

UMS		UTelligent	Admir
🚳 Dashboard			
O Fan speed	Servio	e Alert Settings Filter Alert Settings	
Environment  Alerts  Reporting  Settings  i User manual	Filter Alert Filter Alert Date	<ul> <li>On          Off         DI/DI/2020         Filter Alert Information         Filter Alert when the date of activation has been reached a new table row will appear on the databoard and show as Active and the LED on the cabinet door will change to Amber         Filter Alert On/Off turns on the filter alert feature         Filter Alert On/Off turns on the filter alert feature         Filter Alert Date allows you to choose the date for this alert to be activated         Activate Alert activates this alert         Dismiss will deactivate the alert and remove alert notifications     </li> </ul>	
		USystems Limited © 2020 (v2.0	

### **Filter Alert**

Depending on the environment that the enclosure is situated could result in the enclosure absorbing dust so it is recommended to each customer to use a filter to prevent your IT equipment from unwanted material in the air. If your enclosure has a filter it is also recommend using this feature to notify alert when it may need cleaning or replacing.

To activate this option simple select the 'On' button and click on the date to choice or type it in yourself, then select save.

### WebUI - Alarm Reporting

UMS	=	UTel	ligent	Administrator
🍘 Dashboard				
O Fan speed	Alarms Log	Temperature Log	Humidity L	og Fans Log
Environment	Show 10 v entries		Search:	
Alerts	Date and Time	2 Alarm	Status	Alarms Log Information
Reporting	2020-07-09 07:47:09	FAN2	FAIL	Details the alarms that have occured during its opperation
Security	2020-07-09 07:47:05	FAN1	FAIL	Filter Select the headers to filter the results. Show more records by selecting the records per page drop down. Search by entering the date and it will
🗲 Settings	2020-07-09 06:41:14	HUMID1	FAIL	display all of the alarms of that given date Download Logs will download a .XLSX or .CSV file of all of the alarms
i User manual	2020-07-09 05:20:17	ТЕМРЗ	FAIL	
	2020-07-09 05:20:17	HUMID3	FAIL	
	2020-07-09 00:15:13	TEMP4	FAIL	
	2020-07-09 00:15:13	HUMID4	FAIL	
	2020-07-08 04:14:54	ТЕМРЗ	FAIL	
	2020-07-08 04:14:54	HUMID3	FAIL	
	2020-07-08 01:21:39	TEMP1	FAIL	
	Showing 1 to 10 of 82 entries	Previous	1 2 3 4 5 9 Next	
	Download Logs			
		USystems Limited © 2019-202	0   v2.0	

The Alarms Log report is a list of alarms recorded for up to 3 months. This includes Fan fail, access and temperature over threshold data, reports of the data are available to download onto a .csv spreadsheet.

The records may be displayed 10, 25, 50 or 100 per page.

Search by date and time using the same format from 'timedate' column.

### WebUI - Temperature Reporting

UMS	≡						<b>U</b> Tellige	nt				💧 Administrat
🚯 Dashboard			_									
O Fan speed		Alarms Log			Temper	ature Loj	3			Humidity Log	Fans Log	
Environment	Show	10 v entries						Search	h:		Temperature Log Information	
Alerts		Date and Time	Temp. Sensor1	١ţ	Temp. Sensor2	١ţ	Temp. Sensor3	î	Temp. Sensor4	11	remperature Log mormation	
Reporting		2020-07-09 10:30:38	21.8° C		22.3° C		22.4° C		22.4° C		Details the temperature sensor recordings during its operation	
		2020-07-09 10:30:36	21.8° C		22.3° C		22.4° C		22.3° C		Filter Select the headers to filter this results. Show more records by the records per page drop down. Search by entering the date and i	selecting t will
Settings		2020-07-09 10:30:33	21.8° C		22.3° C		22.4° C		22.3° C		display all of the temprature recordings over the given date Download Logs will download a .XLSX or .CSV fiel of all the tempera	iture logs
User manual		2020-07-09 10:30:31	21.8° C		22.3° C		22.4° C		22.3° C			
		2020-07-09 10:30:29	21.8° C		22.3° C		22.4° C		22.3° C			
		2020-07-09 10:30:27	21.8° C		22.3° C		22.4° C		22.4° C			
		2020-07-09 10:30:25	21.8° C		22.3° C		22.4° C		22.4° C			
		2020-07-09 10:30:22	21.8° C		22.3° C		22.4° C		22.4° C			
		2020-07-09 10:30:20	21.8° C		22.3° C		22.4° C		22.4° C			
		2020-07-09 10:30:18	21.8° C		22.3° C		22.5° C		22.4° C			
	Showi	ng 1 to 10 of 368,008 entries					Previous 1 2 3	4 5	36801	Next		
		oownload Logs										
		U5ystems Limited © 2019-2020   v2.0										

The Temperature Log report is a list of temperature recorded up to 3 months. Reports of the data are available to download onto an .csv spreadsheet.

The records may be displayed 10, 25, 50 or 100 per page.

Search by date and time using the same format from 'timedate' column..

### WebUI - Humidity Reporting

UMS	=			UTelliger	nt	🛔 Administrator
🚯 Dashboard				_		
O Fan speed	Alarms Log		Temperature L	og	Humidity Log	Fans Log
S Environment	Show 10 v entries				Search:	Humidity Log Information
Alerts	Date and Time 17	Humidity, Sensor1	Humidity, Sensor2	Humidity, Sensor3	Humidity, Sensor4	Humidity Log information
Reporting	2020-07-09 10:30:38	63.8%	59.5%	59.2%	60.2%	Details the humidity sensor recordings during its operation
Security	2020-07-09 10:30:36	64.0%	60.5%	59.7%	60.1%	Filter Select the headers to filter the results. Show more records by selecting the records per page drop down. Search by entering the date and it will divergently fifth exampling more than a fine date.
Settings	2020-07-09 10:30:33	64.0%	60.5%	59.7%	60.1%	Download Logs will download a .XLSX or .CSV file of all of the humidity logs
User manual	2020-07-09 10:30:31	63.8%	60.8%	59.7%	60.1%	
	2020-07-09 10:30:29	63.8%	60.8%	59.7%	60.1%	
	2020-07-09 10:30:27	63.8%	59.5%	59.7%	60.2%	
	2020-07-09 10:30:25	63.8%	59.5%	59.7%	60.2%	
	2020-07-09 10:30:22	63.7%	60.5%	59.5%	60.0%	
	2020-07-09 10:30:20	63.7%	60.5%	59.5%	60.0%	
	2020-07-09 10:30:18	63.7%	60.5%	59.5%	59.2%	
	Showing 1 to 10 of 368,004 entri	es		Previous 1 2 3	4 5 36801 Next	
	Download Logo					
	Download Ebgs					

The Temperature Log report is a list of Humidity recorded up to 3 months. Reports of the data are available to download onto an .csv spreadsheet.

The records may be displayed 10, 25, 50 or 100 per page.

Search by date and time using the same format from 'timedate' column..

### WebUI - Fan Reporting

UMS	■ <i>U</i> Telligent								
ն Dashboard									
C) Fan speed	Alarms Log	Temperature Log	Humidity Lo	g Fans Log					
Environment	Show 10 v entries		Search:	Fane Log Information					
Alerts	Date and Time	↓F Fan1 Speed ↓↑	Fan2 Speed	rais cog mornadon					
Reporting	2020-07-09 10:30:38	0	0	Details the fan rpm that have occured during it opperation					
Security	2020-07-09 10:30:36	0	0	the records per page drop down. Search by entering the date and it will disclose the second set that show that set of the second set of t					
Settings	2020-07-09 10:30:33	0	0	uisplay the rpin speed of that given date. will allow you to download as .XLSX or .CSV file of all the RPM speeds.					
User manual	2020-07-09 10:30:31	0	0						
	2020-07-09 10:30:29	0	0						
	2020-07-09 10:30:27	0	0						
	2020-07-09 10:30:25	0	0						
	2020-07-09 10:30:22	0	0						
	2020-07-09 10:30:20	0	0						
	2020-07-09 10:30:18	0	0						
	Showing 1 to 10 of 368,001 entries	Previous	1 2 3 4 5 36801 Next						
	Download Logs								

The Fans Log report is the list of fans connected to the EMS and it's RPM output recorded for up to 3 months. Reports of the data are available to download onto a .csv spreadsheet.

The records may be displayed 10, 25, 50 or 100 per page.

Search by date and time using the same format from 'timedate' column..

#### WebUI - Setting

#### **Network Settings TAB**

The default network settings are as follows:

Device name: EMSXXXXXX DHCP: Set to 'Off' IP address: 192.168.0.10

Netmask: 255.255.252.0

Gateway: 0.0.0.0

To change these settings select the text fields and adjust accordingly and then click Save Settings. If the IP address is changed reconnect using the new IP address after the EMS has been restarted. Do this by selecting restart from the power icon button on the top right of the screen, allow up to 3 minutes for it to power on fully with the new IP address. Type the new IP address into the browser.

NTP Server IP: To change to a different NTP Server enter it's IP Address and use the Save Settings button, a restart of the EMS is required to apply these settings.

MAC address: Displays device's MAC (Media Access Control) address. This cannot be changed.

Serial number: Displays the serial number assigned to the EMS

To change the date and time for your country select the drop down menu and select your time zone and restart the EMSfor the setting to change.

#### **SMTP Settings**

This must be set to allow emails alerts/alarms to be sent.

- Server address (IP/Domain): Add the IP or Domain of your email server
- Username: Add the email address which will the alarms from
- Password: Add the password of the email address

Make sure that the default admin email address is changed to the administrator who is going to be receiving emails to change passwords of users that request a forgotten password.

To make sure that the setting used are correct select the 'Save Settings' button.

Use 'Send Test Email' to test if the settings are correct and working with the EMS. A email address must be entered to send the test email too.

To use the Send Test Email and alarms select the 'Add new email'. Select the alarms for each email address entered.

#### **Device manager**

This tab details all devices that are attached to the EMS. When adding new devices to the EMS cross check in device manager that they are displaying correctly.

Hardware Version - This displays the hardware version of the EMS. This may be required for support. Software Version - This displays the software version of the EMS. This may be required for support.

### **Device manager**

Hardware version: Displays device's hardware version
Software version: Displays the device's software version
Default Units: Change between Metric to Imperial
Servo: If 1 or 2 servos are connected to the EMS this must be selected to 'ON' for the EMS to control the servos
Universal U1 - U4 Input Type: Select the sensor type that is added to these ports on the EMS
IO 1 - 6 Sensor Type: Select which digital sensor is plugged into the EMS
Camera 1: Select the camera from the drop-down menu, if unable to find any make sure that the USB cable from the camera is plugged into any of the USB ports.
Camera 2: Select the camera from the drop-down menu, if unable to find any make sure that the USB cable from the camera is plugged into any of the USB ports.

UTelligent Locking Address: Add the IP address of the UTelligent locking system into the text boxes and selecting the save icon when complete. This will then display on the dashboard.

### **User Accounts**

On first login to the device it will have a default login ('Admin') and password ('Admin12\$') it is recommend to change the Admin login password.

To add a new user select the Add User button at the bottom of the table then fill the fields with the required information. .

There are 5 levels of access -

R (Read-only user) can only access DASHBOARD TAB

RC (Read-only + camera user) can only access DASHBOARD + Camera TAB

W (Write user) access to all TABs other than Camera and EMS settings TAB

WC (Write and Camera user) can access almost all TABs other than EMS Settings TAB

S (Super-user) can access all TABs

Once completed select 'Save Settings'.

Passwords must be a minimum of 8 characters with at least 1 number and 1 upper case letter.

If the account is not required there are two options depending on the situation. If the user is no longer needed for the foreseeable future the account can be removed by selecting the bin icon in the users row. The other option is to deactivate the account in the event that it needs to be suspended, this is achieved by selecting the tick icon on the users row. To reactivate it, select the cross icon. These options can only be performed by the admin account or super user.

Change the email address of the account by editing the text field under email and select save icon when finished, this is the same for the Access level. Enter the user rights by the corresponding letters list in on information panel and selecting save once completed, a confirmation pop up will appear if correct. If incorrect entries have been entered a different pop up will appear showing error inputs.

#### Sensor Names

The table displays each sensor assigned to the EMS and provides the ability to name each device. To change the name, select the text field and type what is required. A good example would be to name a contact sensor in the front to 'Front door' which will show on the dashboard.

#### <u>SNMP</u>

#### **Trap Receiver**

Specifies the destination to which the EMS should send SNMP traps.

#### Туре

The type of trap to send. The EMS sends SNMP v2c Inform traps.

#### **Trap Receiver IP Address**

Enter the IP Address of your SNMP Trap Receiver. Leave blank to disable traps.

#### **Trap Community**

Enter the community string to be sent in SNMP traps.

#### Actions

Select the save icon to save the settings.

#### SNMP v3 Users

The table defines users who are granted access to the EMS for SNMP operations. The details of the relevant user should be entered into the SNMP client application in order to access the EMS.

#### Name

The SNMP user name. Two users are defined: ems-ro for read-only access; ems-rw for read-write access.

#### Level

The security level to be used for SNMP operations. This can not be changed from the pre-set authentication and privacy.

### **Auth Protocol**

The protocol to be used when authenticating the user. Select the from the list.

#### **Authentication Passphrase**

The passphrase required to authenticate SNMP requests for this user. An authentication passphrase is required. Leave the passphrase blank to deny access for the user.

#### **Priv Protocol**

The protocol to be used for data privacy. Select from the list.

### **Privacy Passphrase**

The passphrase to be used for data privacy. If left blank the Authentication passphrase will be used.

### Actions

Select the save icon to save the settings for the SNMP v3 user. Note: when changing any user parameters, please also type an authentication passphrase into the field provided, even if a passphrase is already set, otherwise access will be disabled for the user.

### SNMP v2c Community Strings

Community strings are used to grant SNMP v2c access to the EMS.

### Permissions

The level of access to be granted for the community: Read-only the rocommunity for read-only access; Read-write the rwcommunity for read-write access.

### **Community String**

The name of the community. Leave blank to disable this type of access.

### Actions

Select the save icon to save the settings for the SNMP v2c community.

#### **Further Documentation**

For additional information, please refer to the below. Available through your USystems representative, or our central inquires line at sales@usystems.com

Complete Product Range

Operations and Maintenance Manual

Troubleshooting Guide

Product Datasheet

Available at www.usystems.com

Please contact sales@usystems.com

Please contact sales@usystems.com

Available at www.usystems.com







### We engineer for a sustainable tomorrow.

www.usystems.com

Europe

Systems House, 235 Ampthill Road Bedford, MK42 9QG, UK

Tel: +44 (0) 1234 761 720

Middle East

Unit 706B, Al Shamsi Building, Al Nahda 1, Dubai, United Arab Emirates

Tel: 97 155 998 1198

North America

10 Glenlake Parkway, Suite 130 Atlanta, Georgia, 30328, USA

Tel: 404 334 3607

India

207, 2nd Floor Regus Supreme (Jayanagar), 44/1, 16th Cross, Jayanagar, 7th block (west), KR Road, Bangalore - 560070, India

Tel: 080 6185 2022

#### **Further Documentation**

For additional information, please refer to the below. Available through your USystems representative, or our central inquires line at sales@usystems.com

Complete Product Range

Operations and Maintenance Manual

Troubleshooting Guide

Product Datasheet

Available at www.usystems.com Please contact sales@usystems.com Please contact sales@usystems.com Available at www.usystems.com



EDGE MDCs



### We engineer for a sustainable tomorrow.

www.usystems.com

Europe

Systems House, 235 Ampthill Road Bedford, MK42 9QG, UK

Tel: +44 (0) 1234 761 720

#### Middle East

Unit 706B, Al Shamsi Building, Al Nahda 1, Dubai, United Arab Emirates

Tel: 97 155 998 1198

North America

10 Glenlake Parkway, Suite 130 Atlanta, Georgia, 30328, USA

Tel: 404 334 3607

India

207, 2nd Floor Regus Supreme (Jayanagar), 44/1, 16th Cross, Jayanagar, 7th block (west), KR Road, Bangalore - 560070, India

Tel: 080 6185 2022